



Victaulic 3D Piping Software Install  
AutoCAD 2015 - 2016


- After downloading the required version, locate and open the ZIP file
- Double click on the MSI file
- The following dialog box will be displayed . . .



- If prompted, select **Yes** in the **User Account Control** dialog box



- The following dialog box will be displayed . . .




~ End of Install ~

To Display Victaulic 3D Piping Software Toolbar  
AutoCAD 2015 - 2016


- Launch AutoCAD (Be sure to **run as an administrator**)
- Start a new drawing
- **Right mouse click** in the drawing area and select **Options...** from the pop-up menu
- On the **Profiles** tab, change the active profile to **Victaulic** and click **OK** to close the dialog box
- Type **MENUBAR** and set the variable to **1**
- Type **MENULOAD**
- Click **Browse** and locate the **VICTAULIC.cuix** file. By default, the path is as follows . . .

C:\ProgramData\Autodesk\ApplicationPlugins\Victaulic3DPipingInstaller.bundle\Contents

- Highlight the menu file and select **Open**
- Select the **Load** button and click **Close** to exit the Load/Unload Customizations dialog box



- The Victaulic menu will appear on the menu bar at the top of the AutoCAD work area (see below)



~ End of Setup ~